



Five Speed Manual Gearbox Shift Selection

1972-78
Models




1979-85
Models


Selector Lever 1968-85



Gear Engagement 1968-85



Gear Selector 1968-72



Gear Selector 1973-85

Illus. No.	Part No.	Description
1.	4239756	Shift Knob 1972-78
	4458681	Wooden Knob 1979-83
	5881160	Black Leather Knob 1980-83
	5887195	Black Leather Knob 1984-85
	7536751	Brown Leather Knob 1984-85
2.	7536752	Chrome Shaft 1972-85
3.	4193249	Pad
4.	4137841	Bushing
5.	4137842	Collar
6.	4137843	Locktab
7.	4301588	Shift Lever 1973-85
8.	16100811	Nut
9.	10516674	Lockwasher

Illus. No.	Part No.	Description
10.	13543521	Stud
11.	4326537	Cover
12.	14328701	Cap
13.	4074250	Bushing
14.	10516474	Lockwasher
15.	4170541	Alignment Pin
16.	4170540	Gasket
17.	4163972	Cover
18.	4148579	Reverse Lockout
19.	10791021	Nut
20.	10902231	Bolt
21.	4221622	Boot
22.	13826324	Bolt

Illus. No.	Part No.	Description
23.	4289490	Shift Shaft
24.	4308774	Spring
25.	870736	Pivot
26.	4289497	Cover
27.	4289498	Plate
28.	12638620	Washer
29.	14048211	Nut
30.	4289489	Cover
31.	13824611	Bolt
32.	10902231	Bolt
33.	4163918	Gasket
34.	4163912	Shaft
35.	4163911	Spring
36.	4163915	Bushing